

Users' Manual / 使用说明书



YAMAHA

(For All Clubs)

After reading this manual, store it in a safe place with the warranty form. Please ask the dealer where you purchased the product for the warranty form, ensuring that it contains the purchase information such as the dealer's seal and date of purchase. Loss of the warranty form will forfeit your warranty benefits even if it occurs during the warranty period. Please note that the warranty form cannot be reissued.

For Safe Golfing

Learn how to use, maintain, and store your golf clubs correctly. Follow the "Warnings" and "Cautions" below to enjoy safe and pleasurable golfing.

Warning



Ensure that all parts of the club are in good condition.

Ensure that the head, shaft, grip, screw parts, weights, and other parts are in good condition before using the club.



Use a club that matches your strength.

Using a club intended for senior citizens or ladies may damage the shaft or head of the club if you are physically strong. Please use clubs that match your physical strength.



Ensure the safety of the surroundings before you swing.

Ensure the safety of the surroundings before you swing to prevent accidents. In addition, never use a club where there is foot traffic, such as streets or parks.



Replace a worn-out grip sooner rather than later.

Clubs may slip during a swing, causing an accident. Make sure to replace a slippery grip due to wear or deterioration.



Do not use a putter in the way you use other clubs.

The designed use of a putter is for putting and approaching from near the green. Please do not use it for other purposes.



Make sure to check the club after it receives a strong shock.

If the club accidentally hits the ground (duff), immediately check the condition of the neck and the shaft. Using a club in bad condition may cause an accident. When the club receives a strong shock after accidentally hitting a tree, building, stone, or metallic object, check it as well.

Caution



Protect the club head using a cover.

Use a head cover for a wood club when not in use to protect against scratches.



Do not touch broken portions of a head or shaft.

Never touch any broken part to prevent injury. Use a tape or something similar to cover the broken part, and have it repaired immediately.



Do not place a large load on the shaft.

Do not bend or twist the shaft with excessive force to prevent the shaft from breaking.



Replace a scratched shaft immediately.

Replace a scratched shaft immediately to prevent it from breaking.



Do not use the neck to hit the ball intentionally.

Hitting the ball with the neck may cause the shaft to break.



Do not step on or stomp the club.

Do not step on or stomp the club. In addition, do not use the club for other purposes than playing golf.



Be careful when retrieving and storing clubs to/from the cart bag.

Be careful not to place too much load on the clubs when retrieving and storing them to/from the cart bag. In addition, be careful not to let a cart bag with clubs inside fall.



Be careful when transporting clubs.

When transporting clubs, use a cart bag or something similar to prevent scratches.

Indicates a prohibited action. Indicates an action you must take.

Please Do Not Forget to Clean Your Golf Clubs After Use to Protect Them From Moisture and Rust

How To Clean the Club Head

- 1 Brush off any sand, mud, and grass on the face or sole of the clubs.
- 2 Use a dry cloth to wipe off any small stains and moisture.
- 3 Apply evenly an oil or cleaning product available at stores.
- 4 Finish by polishing with a dry cloth

How To Clean the Shaft

- 1 Use a dry cloth to wipe off any dust, mud, and stains.
- 2 Apply evenly an oil or cleaning product available at stores.
- 3 For a steel shaft, use a dry cloth to wipe off completely any stains and moisture after use to prevent rust. Especially if used in a rain, dry the club in a shady place with good ventilation.

How To Clean the Rubber Grip

- 1 Use a dry cloth to wipe off any dust, mud, and stains.

How To Clean the Club After Using It in a Rain

- 1 Use a dry cloth to wipe off the moisture completely, and dry the club in a shady place with good ventilation.
* Take the clubs out of the cart bag, and remove the head cover.
- 2 Clean each part of the clubs after they are completely dry.

Notes on Cleaning Certain Materials and Surfaces

Iron and Steel

The surface of the head made of iron or steel is plated. As the plated film is extremely thin, do not use strongly acidic anti-rust product containing abrasives, cleansers, or steel wool. Doing so may damage the head, causing rust.

Painted Surfaces

To clean painted surfaces, use a cleaner made for golf clubs that do not contain abrasives.

Titanium, Stainless Steel, Aluminum, and Copper Alloys

To prevent rust and corrosion, remove moisture and stains, and store the product in place with low humidity.

Surface Processed With Ion Plating (IP)

Peeled IP cannot be re-processed. To avoid scratches, do not use steel wool or a metallic brush for cleaning.

How To Store Clubs

- Avoid places with high temperature and high humidity.
- Do not place clubs in the trunk of a vehicle or expose them to sunlight for a long time.
- Do not put clubs close to fire.
- Manage your club storage so that children do not retrieve the clubs to swing them around.
- Store clubs where there is no danger of items falling on them.

How To Repair the Club

Attempts to repair the product yourself may cause safety problems. Make sure to ask the dealer where you bought your product to repair it for you.

Alternations

We are not responsible for any damage to an altered club, or any accident caused by such alteration.

Environmental Conservation

When disposing of the product, contact your local organization which handles waste disposal to obtain the correct disposal method. Do not dispose of the product in an irresponsible manner, such as in your household trash.



YAMAHA

Warranty

This product has passed our strict quality inspection. Should a failure occur during the warranty period due to a problem in quality or manufacturing, we will either repair or replace the product with no charge in compliance with the warranty rule indicated on the reverse side. Keep this warranty form in a safe place.

To be filled out by the dealer

| | |
|-------------------------|--------------------------------|
| Product Name | |
| Serial Number | |
| Dealer Name and Address | |
| TEL | |
| Date of Purchase | Month _____ Day _____, 20_____ |

To be filled out by the customer

| | |
|-----------------|--|
| Name | |
| Warranty Period | Two years from the date of purchase |

<Warranty Rule> *Please read.

1. If, with normal handling, a failure should occur during the warranty period due to a problem in quality or manufacturing, we will either repair or replace the product with no charge. Please bring and present the product and this warranty to the dealer where you purchased it.
2. Please note that this warranty does not apply to the following cases, even during the warranty period.
 - a) Damage caused by a fire, natural or terrestrial disaster.
 - b) Damage caused by poor storage management (for example, damage caused due to placement under a weighty object or high temperature such as in a vehicle exposed to direct sunlight for a long time).
 - c) Clubs that are identified to have been altered (except for a replaced grip).
 - d) Damage identified to have occurred due to significant abuse or poor handling.
 - e) Damage caused by an accident that occurred during use for purposes other than those intended, or an unforeseen accident that occurred during use.
 - f) Other instances that are equivalent to above.
4. We provide the warranty and after-sales services using the date of purchase and manufacture number information. Please note that we may refuse to warrant products for which the dates of purchase have been modified, or whose manufacture numbers have been intentionally modified or lost.
5. We may not be able to warrant products without the warranty form.
6. The warranty forms are not re-issuable.

<After-Sales Services Rule>

Fee-based repairs will be provided for products for which the free-repair period has passed based on the warranty rule or in-warranty products to which free repair does not apply (please ask your dealer regarding details such as the repair fees and repair time).

You will be responsible for the shipping cost for the product to be repaired. As a general rule, we decline to repair in any of the following cases.

- a) A specification change that is determined to significantly affect the functions of the golf club.
 - b) A repair of a product or part thereof that is determined not to be repairable.
- This warranty form will not be reissued. The warranty form will be necessary for after-sales services or free repair.
 - Please read the warranty and after-sales services rules on the reverse side.
 - Your personal information will be used for service activities during the warranty period, and the after-sales services after the warranty has expired.

Golf HS Division

Yamaha Corporation 283 Aoya-cho, Minami-ku, Hamamatsu,

Shizuoka Prefecture, 435-8567, Japan

Version:1